

### Pre-Install Check List

- Compatible replacement bolt for assembly?
- Make sure connector is clean and free of damage.
- Gather necessary tooling
  - Small flat head screwdriver
  - Needle nose pliers



1) Insert screwdriver blade under the snap ring and use a twisting motion to pry it out.



2) Fully remove existing shear bolt.



3) Make sure threads are clean and install a new shear bolt.



4) Align the new snap ring into the existing slot on the shear bolt.



5) Squeeze snap ring into the slot until it is securely fastened.